

**IPS e.max<sup>®</sup>**

**All-Ceramic Chairside  
Preparation Guide for  
IPS e.max<sup>®</sup>**

## Anterior chairside preparation guide


### Full-coverage

#### Anterior crown preparation



### 3-unit bridge restorations

#### 3-unit bridge preparation



### Veneers

A medium grit, round-ended, diamond bur is used to remove a uniform thickness of facial enamel by joining the depth-cut grooves.

The diamond bur is angled to bevel back the incisal edge.



### Thin Veneers

IPS e.max can be pressed to as thin as 0.3 mm for veneers. If sufficient space is present, IPS e.max can be placed over the existing teeth without the removal of any tooth structure. Depending on the case requirements, however, some teeth may need to be prepared to accommodate for the thickness of the ceramic and to ensure for proper contour and emergence profile.



\*Please note: For additional masking capabilities and/or layering techniques, further reduction may be necessary. Contact us for further information.

## Posterior chairside preparation guide


### Inlays/Onlays

#### Inlay preparation




### 3-unit bridge restorations

#### 3-unit bridge preparation



### Full-coverage restorations

#### Posterior crown preparation



#### Conventional cementation preparation

